


For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
(Black) (White) (Biscuit) (Stainless)

30" Freestanding
GAS OVEN
CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	9763445	Bracket, Burner	19		Cap, Burner
	W10118262	Installation	10	9756821	Support, Wiring			6K (RF, LR)
		Instructions	12		Grate, Burner		8284669	Coal Black
	W10118261	Use & Care Guide			Right		9761562SD	Satin Cumberland
		Tech Sheet		9761555CB	Coal Black		9761562SN	Satin Moleskin
	W10112145	English		9761555SD	Satin Cumberland			12.5K (RR)
	W10112146	French		9761555SN	Satin Moleskin		9761563CB	Coal Black
	9757680	Anti-Tip	13		Grate, Burner		9761563SD	Satin Cumberland
		Instructions			Left		9761563SN	Satin Moleskin
		Safe Cooking Tips		9761556CB	Coal Black	20	4449809	Screw
	9762761	English		9761556SD	Satin Cumberland	21	3196160	Screw
	9759133	French		9761556SN	Stain Moleskin	23	9759627	Cover, Cooktop
	9763467	Guide Easy Set	16	9759944	Thermostat (60c)			Rear
			17		Vent, Center	24	9763436	Cover, Top Rear
2	W10153103	Burner Box		9760225BL	Black	25		Head, Burner
3	9761784	Bracket, Mounting		9760225WH	White		8286181	LR, RF
4		Cooktop		9760225BT	Biscuit		8286182	RR
	W10106250	Black/Stainless	18		Grate, Insert	26	W10109920	Gasket (Tape)
	W10106270	White		9761557CB	Coal Black			
	W10106260	Biscuit		9761557SD	Satin Cumberland			
5	3196537	Screw		9761557SN	Satin Moleskin			
7	3400843	Screw						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)


(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	15	W10074200	Gasket, Door	43	W10110534	Base, Chassis
	W10109540	Black	17	4452152	Bracket, Mounting	49	4448933	Retainer, Gasket
	W10109570	White	18	9757685	Guide, Side Panel	50	W10112206	Cover, Back
	W10109550	Biscuit	19	9757461	Bracket, Side Panel	51	4449809	Screw
	W10140548	Stainless	20		Oven, Side Panel	54		Vent, Bottom Upper
		Left		9760723PB	Black		9756481BL	Black
	W10109490	Black		9760723PW	White		9756481WH	White
	W10109520	White		9760723PC	Biscuit		9756481BT	Biscuit
	W10109500	Biscuit	21	9757811	Brace, Side Panel		9756481SS	Stainless
	W10140547	Stainless	22	9760888	Latch, Motorized	55		Trim, Bottom Vent
2	8053971	Brace, Main Back	23	9757807	Thermostat		W10104890	Black
3		Hinge Receiver	24	9759890	Clip, Side Panel		W10104910	White
	4455606	Right	25	4455641	Side, Chassis		W10104900	Biscuit
	4455605	Left	26	9759762	Back, Chassis		W10104870	Stainless
4	W10105790	Bumper, Door	27		Liner, Oven	FOLLOWING PARTS NOT ILLUSTRATED		
5	4448444	Grommet		9759945	Standoff, Rear	INSULATION		
6	3400832	Screw	28		Sensor		9756817	Insulation, Wrap
7	8303099	Top Chassis	29	W10131825	Bracket, GOC		9756470	Insulation, Back
8	9759722	Insulation, Body Side Trim	30	9756454	Slide, DSI			
9	9761666	Tube, Vent	31	9760223	Slide, GOC			
10	W10067870	Lens, Light	32	W10083460	Central, Appliance			
11	W10009930	Assembly, Oven Light	33	9762774	Screw			
12	4452166	Bulb, Light	34	3196537	Washer, Insulation			
13	9757732	Shield, Heat	35	9760481	Body Side Trim			
14	W10130368	Frame, Front	37	9759242	Thermostat (TOD)			
			41	4449743	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
(Black) (White) (Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13	8522415	Seal, Window
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10131890	Biscuit
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774BT	Biscuit
	8303774SS	Stainless
16	3196184	Screw
17	4448520	Bumper, Door (3)
18		Badge
	8304603BL	Black
	8304603WH	White
	8304603BT	Biscuit
	8304603SS	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER PARTS


For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot


Illus. No.	Part No.	DESCRIPTION
8	3196037	Foot Assembly
10	W10140539	Drawer
11		Guide, Roller
		Includes Roller
	W10019810	Right
	W10019800	Left
12	W10140544	Panel, Drawer
13		Front, Drawer
	9761747BL	Black
	9761747WH	White
	9761747BT	Biscuit
	W10140545	Stainless

Illus. No.	Part No.	DESCRIPTION
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573BT	Biscuit
	9761573SS	Stainless
15	3196537	Screw
16	8274149	Thermistor
17	9760775	Element, Warming
18	4449809	Screw
19	9758676	Support, Element
23	9761796	Enclosure, Warming Drawer
24	W10153099	Cover, Access
25	3400805	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
 (Black) (White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10118278	Front, Air Duct
2	W10068590	Top, Air Duct
	W10068600	Right
		Left
3	9759320	Blower
4	4451758	Block, Foam
7	9757829	Bracket, Transformer
8	W10111628	Transformer
9	3196537	Screw
10	4449040	Screw
11	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS


For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752980	Shield, Flame
2	4451583	Motor, Convection
5	9757779	Fitting, Broiler
6	4448717	Rack, Oven
7	9760776	Element, Broil
8	4453957	Pan Support, Bake
9	9760228	Electrode, Bake
10	9760228	Burner, Bake Log
11	9752737	Shield, Oven
12	4453984	Shield, Bake Flame
	3196176	Screw


Illus. No.	Part No.	DESCRIPTION
13	9763716	Valve, Assemble
14	9756831	Tube, Broil
15	W10111219	Burner, Broil
16	8054129	Ignitor, Broil
17	4454009	Cover, Ignitor
18	4453920	Pan, Oven Bottom
19	9760777	Element, Convect
20	W10104790	Cover, Fan
21	9755542	Probe, Meat

Illus. No.	Part No.	DESCRIPTION
23		Shield, Element
	W10153093	Right
	W10153094	Left
24	W10105420	Diverter, Air
25	W10116351	Blade, Fan
26	W10116349	Nut
27	9755543	Jack, Meat Probe
28	9755547	Washer, Lock External
29	9755546	Hex Nut
30	3196176	Screw
31	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
 (Black) (White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10128446 LR, RF W10128455 RR	Burner Base
2	9761069	Tubing, Burner(RF)
3	9761070	Tubing, Burner(RR)
4	W10110378	Igniter, Orifice Holder
5	9761068	Tubing, Burner(LR)


Illus. No.	Part No.	DESCRIPTION
6	9762937 LR, RF 9762938 RR	Orifice
7	4456816	Valve, Burner Small (2)
8	4456817	Valve, Burner Large
10	9761648	Tube, Manifold

Illus. No.	Part No.	DESCRIPTION
11		Manifold
	9761641	TCB
	9761642	Cooktop
12	3196537	Screw
13	8273062	Screw
14	8523704	Bolt, Valve (4)
18	4453754	Tubing GDS to Manifold


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TRIPLE CROWN BURNER

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
 (Black) (White) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9761639	Burner Assembly Triple Crown Burner
2	8285250	Plate, Closure
3	8285255	Internal Head, Triple Crown
4	8285256	External Head, Triple Crown Burner
5		Cap, Burner External
	8285258	Matte Black
	8285258SD	Satin Cumberland
	8285258SN	Satin Moleskin
6		Cap, Burner Internal
	9758829CB	Matte Black
	9758829SD	Satin Cumberland
	9758829SN	Satin Moleskin
7	3400702	Screw
8	3400843	Screw
9	9760519	Valve, T.C.B.
10		Tube, T.C.B. Gas
	9761072	Outer
	9761071	Inner
11		Orifice
	9762443	Internal
	9762442	External
12	9763494	Igniter



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01
 (Black) (White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10117036	Control Panel Black
	W10117038	White
	W10117037	Biscuit
	W10156273	Stainless
2	9761566	Switch, Membrane
3	9762794	Control, Interface
4	W10105370	Shield, Console
5	3196537	Screw

Illus. No.	Part No.	DESCRIPTION
6	9757409	Support, Gas Valve
7	9761745	Bracket, Touchsensor
9		Knob, Burner RF, RR, LR
	W10130373	Black
	W10130374	White
	W10130375	Biscuit
	W10156265	Stainless

Illus. No.	Part No.	DESCRIPTION
10	9758080	Module, Spark
11		Knob, TCB LF
	W10130383	Black
	W10130384	White
	W10130385	Biscuit
	W10156262	Stainless
12	9780271	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KGSS907SBL01, KGSS907SWH01, KGSS907SBT01, KGSS907SSS01

(Black)

(White)

(Biscuit)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT.</u>		
<u>LENGTH</u>		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242827	Wire (14 Ga. 150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
	W10118724	Harness, Main
	9762904	Harness, Bake/ Broil Ingiter
	9756824	Harness, Spark Switches
	W10110533	Harness, Warming Drawer
	9756921	Harness, Triple Crown Burner
	9762921	Harness, Communication
	9763481	Harness, Ground Strap
	W10155291	Connector, Flex
	4449809	Screw
	4450800	Screw, Ground
	4452222	Spacer, Harness
<u>Miscellaneous</u>		
	4455352	Bracket, Blower
	9757426	LP Orifice Kit
	9758677	Power Cord
	9782676	Anti-Tip, Assembly Filler, Countertop
	W10113902A	Black
	W10113903A	White
	W10113904A	Biscuit
	W10113901A	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST